


# **Jupiter-Pro XL Convertible**

## **Line-interactive Sine Wave UPS**

User's Guide

JP-Pro XL 1000/1500/2000/3000



## Contents

<b>1 JUPITER-PRO XL</b>	<b>2</b>
Introduction	2
<b>2 IMPORTANT SAFETY INSTRUCTION</b>	<b>3</b>
<b>3 SETUP</b>	<b>5</b>
Inspection	5
Placing the UPS properly	5
Unpacking	5
Selecting Installation Position	6
UPS Setup	7
Tower Setup	7
Rack-Mount Setup	9
UPS Front Panel	11
LCD Display Panel	12
UPS Real Panel	12
JP-Pro XL 1000/1500	12
JP-Pro XL 2000	13
JP-Pro XL 3000	14
<b>4 INSTALLATION</b>	<b>15</b>
Connect Utility and Load	15
Connect Network Surge Protection	15
Connect Computer Interface Port	16
Connect with Extended Battery Bank	16
Install the UPS with the Extended Battery Bank	17
Connect the Extended Battery Bank to the UPS	18
<b>5 OPERATION</b>	<b>19</b>
Turn on the UPS	19
Turn off the UPS	19
Plug-in Charge	20
Auto Restart	20
Alarm Silence	20
Self test	20
<b>6 UPS MAINTENANCE</b>	<b>22</b>
Battery Replacement	22
How to Replace Battery	23
Recycling the Used Battery	23
<b>7 SPECIFICATIONS</b>	<b>24</b>

## CHAPTER 1

### Introduction

The JP-Pro XL Convertible UPS series, featured with Tower/Rack Convertible design, Double AVR Boost and Double Buck, Pure Sine Wave Output, User's Friendly LCD Display, Built-in customer Option Slot, Hot Swappable Battery, and USB/RS232 Communication interface, provides a flexible from factor for most of business critical file server, minicomputers, network switches and hubs, etc. in tower or rack mount formats.

- Sine Wave Output provides assurance of compatibility with all kinds of loads.
- User's Friendly LCD panel may display system status including load level, battery level, AVR-Boost/Buck and fault status for easy service.
- 90% High Efficiency in Normal Mode meets high energy saving standard and reduces noise and heat generated by other topology UPS.
- Easy Swappable Battery Function may save the time and money by swapping the batteries by end-user without sending it back for a factory service.
- Cold Start Function enables to turn on the UPS without connecting to the Utility.
- Optional Communication Software allows not only the control of the UPS and graceful shutdown when the Utility Fails, but also allows the user to remotely test the major operating functions of the UPS, communicate via SNMP/web/network optional card, access UPS functions via the web and alert users via SMS messages against specific events.
- User-friendly Plug and Play design can easily be installed by end user. All units up to 3Kva are supplied with input cables and output sockets as standard.
- Plug-and-play USB/RS232 interface conveniently offers a plug-and-play USB or RS232 port for connecting with nowadays IT products.

## CHAPTER 2

### IMPORTANT SAFETY INSTRUCTION

#### An Important Notice



1. The UPS has its own internal energy source (battery). Should the battery be switched on when no AC power is available, there could be voltage at the output sockets.
2. Make sure that the AC Utility outlet is correctly grounded.
3. Do not open the case, as there are no serviceable parts inside. Your Warranty will be void.
4. Do not try to repair the unit yourself; contact your local supplier or your warranty will be void.
5. Please make sure that the input voltage of the UPS matches the supply voltage.
6. To eliminate any overheating of the UPS, keep all ventilation openings free from obstruction, and do not store "things" on top of the UPS. Keep the UPS 30 cm away from the wall.
7. Make sure the UPS is installed within the proper environment as specified. (0-40°C and 30-90% non-condensing humidity)
8. Do not install the UPS in direct sunlight. Your warranty may be void if the batteries fail.
9. Install the UPS indoors as it is not designed for installation outdoors.
10. Dusty, corrosive and salty environments can do damage to any UPS.
11. Install the UPS away from objects that give off excessive heat and areas that are excessively wet.
12. If liquids are spilt onto the UPS or foreign objects dropped into the unit, the warranty will be null and void.
13. The battery will discharge naturally if the system is unused for any length of time.
14. It should be recharged every 2-3 months if unused. If this is not done, then the warranty will be null and void. When installed and being used, the batteries will be automatically

recharged and kept in top condition.

15. This UPS supports electronic equipment in offices, telecommunications, process control, medical and security applications. Non-authorized technician is not allowed to install the UPS in the following areas.
  - a. Medical equipment directly related to human life
  - b. Elevator, Metro (Subway) system or any other equipment related to human safety.
  - c. Public system or critical computer systems.
16. Do not install the UPS in an environment with sparks, smoke or gas.
17. Make sure the UPS is completely turned off when moving the UPS from one place to another. It might cause electrical shock if the output is not cut completely.

### Storage Instruction



For extended storage through moderate climate, the batteries should be charged for 12 hours every 3 months by plugging the UPS power cord into the wall receptacle. Repeat this procedure every 2 months under high temperature environment.

## CHAPTER 3 SETUP


### Inspection

Inspect the UPS upon receipt. Notify the carrier and dealer if there is damage.

The package is recyclable; save it for reuse or dispose of it properly.

### Place the UPS Properly


The UPS is with microprocessor control, which shall be placed in a well-ventilated & low humid environment.



### Unpacking

1. Take the UPS out of the export carton.
2. Remove the packing materials.
3. Standard Package includes:
  - a. User's Manual
  - b. 1pce x AC Input Power Cord
  - c. 2pcs x IEC output cables ( for the UPS with IEC sockets only)
  - d. 1pce x RJ11 Phone Jack Cable
  - e. 1set x UPS communication kit (optional)

### Accessories for Tower and Rack Mount




### Selecting Installation Position


It is necessary to select a proper environment to install the unit, in order to minimize the possibility of damage to the UPS and extend the life of the UPS.

Please follow the instructions below:

1. Keep at least 20cm(8 inches) clearance from the rear panel of the UPS from the wall or other obstructions.
2. Do not block the air-flow to the ventilation openings of the unit.
3. Please ensure the installation site is in accordance with the UPS working specifications to avoid from overheat and excessive moisture.



4. Do not place the UPS in a dusty or corrosive environment or near any flammable objects.
5. This UPS is not designed for outdoor use.



## UPS Setup


The JP-Pro XL offers a flexible form factor enabling integration into a wide variety of environments. The Jupiter-pro XL series with space-saving design only occupy 2U for 1000 to 3000VA.

If you are installing the UPS in “Tower” type, please proceed Tower Setup; otherwise, proceed “Rack-Mount” Setup.

## Tower Setup


Stand Alone Unit

Step1



Fasten 4pcs “A1” onto the positions as indicated above.


Step2



Fasten “A2” on the position shown then fix “A3” on the top of the A2 with screws as shown.


## Rack-Mount Setup

### Step1




Choose 10 flat-head screws ready for the 10 positions shown.

### Step2




Fasten 2pcs x "B2" onto the positions with 10pcs flat-head screws as  
Shown.

## Step3




Select a proper position and fix a slide-in plate onto the Rack Cabinet.

## Step4





Put the UPS on the top of the slide-in plate.

## Step5




Fix the UPS with 4 screws as indicated as above.

**UPS Front Panel**




### LCD Display Panel




1. Utility LED 
2. Fault LED 
3. On Switch 
4. Off Switch 
5. Battery Replacement LED 
6. Battery Backup LED 
7. Screw for Easy Swappable Battery Cover
8. Battery Low 
9. Bypass 
10. Utility Low, UPS Boost 
11. Utility High, UPS Buck 
12. UPS Output Indicator 
13. Polarity Error or Ground Fault 
14. Overload 
15. Load/Battery Level (%) 
16. Load/Battery Level Indication Control Button 

### UPS Real Panel JP-Pro XL 1000 / 1500




**110/115/120V Rear Panel**




**220/230/240V Rear Panel**

1.RJ45 Port	7.Rating Label
2.DIP Switch	8.Input Fuse
3.USB Communication Port	9.Input Power Socket(Inlet)
4.RS232 Communication Port	
5.Output Breaker	
6.Outlets	

**JP-Pro XL 2000**




**110/115/120V Rear Panel**




**220/230/240V Rear Panel**

1.RJ45 Port	7.Input Power Socket(Inlet)
2.DIP Switch	
3.USB Communication Port	
4.RS232 Communication Port	
5.Output Breaker for 6-1 and 6-3	
6.Outlets	
6-1 NEMA 5-15 Receptacles	
6-2 NEMA 5-20 Receptacles	

6-3 IEC 320-C13 Receptacles

**JP-Pro XL 3000**


110/115/120V Rear Panel



220/230/240V Rear Panel

- 1.RJ45 Port
- 2.DIP Switch
- 3.USB Communication Port
- 4.RS232 Communication Port
- 5.Output Breakers
  - 5-1 Output Breaker for 6-1
  - 5-2 Output Breaker for 6-2
  - 5-3 Output Breaker for 6-4

7.Input Power Socket(Inlet)

## 6.Outlet

- 6-1 NEMA 5-15 Receptacles
- 6-2 NEMA 5-20 Receptacles
- 6-3 Output Power cord L5-30R  
(Optional)
- 6-4 IEC 320-C13 Receptacles
- 6-5 IEC 320-C19 Receptacles  
(Optional)


## CHAPTER 4

## INSTALLATION

### Connect Utility and Load

First, connect the UPS with Utility, then plug the loads onto the Outlets on the rear of the UPS. To use the UPS as a master “On/Off” switch, make sure that all of the loads are switched “on”.

These UPS outlets provide battery backup and surge protection to the equipment when Utility voltage is out of window.




**Caution**


**Do not connect a laser printer to the UPS outlets!**

**Connect Network Surge protection**

Connect a 10 base-T / 100 base-T network cable with the RJ-45 network surge protection “IN” jack on the rear of the UPS. Connect from the “OUT” jack with network cabling to network equipment.

**Connect Computer Interface Port**

Connect the supplied interface cable (RS-232 or USB, Optional) between the interface port on the rear of the UPS and the computer interface port. See software installation guide in the CD-ROM (Optional) for installation purpose.

**Use with Extended Battery Bank**

### Caution




**Battery bank connectors are color-coded as shown below. Do not try to install battery bank with connectors that are different from the battery bank connector in the UPS.**

UPS model	Nominal System Voltage (connector color)	Battery Bank
JP Pro XL 1000	24VDC (red)	BBCJPPXL0124
JP Pro XL 1500	24VDC(red)	BBCJPPXL0524
JP Pro XL 2000	48VDC(yellow)	BBCJPPXL0148
JP Pro XL 3000	48VDC(yellow)	BBCJPPXL0548


### Installation the UPS with the Battery Bank

Step1




Change the direction of the “Feet” as shown.

Step2



Fasten the “A4” with Truss-head screws as shown above.

### Connect the Extended Battery Bank to the UPS



## CHAPTER 5

### OPERATION

#### Turn on the UPS

- 1 Connect the UPS to the wall receptacle. LCD will display "OFF", when Utility is normal. If there is nothing on the LCD, go to step 3.
- 2 Push the "On" Switch on the front panel to start the UPS. Both the LCD and Utility LED (Green) are lit. The start-up procedure is completed and the loads are supplied by the UPS.
- 3 To cold start the UPS, press the "On" Switch on the front panel for approximately 3 seconds until the LCD lights up and buzzer sounds, then release the "On" Switch. The UPS starts operating and Battery Backup LED (Amber) lights up. The cold start-up procedure is

completed and the loads are supplied by the UPS.

- 4 The UPS will run under Backup mode and the buzzer alarms every 2 seconds in case of blackout or over/under voltage. On the contrary, If Utility is back to normal and then the UPS will run under Utility mode and silence alarm.

### Turn Off the UPS

- 1 Press the "Off" Switch for at least 3 seconds to turn off the UPS. If you press the "Off" Switch less than 3 seconds, the UPS will not execute shutdown command due to insufficient pressing time.
- 2 In some occasions, the UPS will shut itself down in case of overload, output short-circuited or battery cut-off point reached in the Backup mode.
- 3 The UPS will automatically shut off the output and beep for 5 seconds then completely shut itself down.

### Plug-in Charge

- 1 If the Input Power Cord is connected to the wall receptacle properly and the Utility is normal, the UPS will start charging automatically without processing "Turn On" procedure.
- 2 You have to charge for at least 8 hours every 3 months to avoid from battery self over-discharge naturally, if the UPS is in an idle condition.

### Auto-Restart

- 1 If the Input Power Cord is connected to the wall receptacle properly and Utility is back to normal, the UPS will automatically restart to provide energy to the output after battery cut.

### Alarm Silence

- 1 The Alarm might be turned off by pressing the "On" Switch for

approximately 1 second in the “Backup” mode.

- 2 Unless any other warning or fault condition occurs, the alarm remains at Silence condition once the “Alarm Silence” is turned off.

### Self Test

- 1 Under Utility Normal condition, press the “On” Switch for 3 seconds to execute the Battery Self-test function.
- 2 In case the battery is normal, it will enter into the Battery Backup Mode for 10 seconds then return to Utility Mode.
- 3 If the battery voltage is detected lower than set limit, the Battery Replacement LED will blink for 5 seconds then extinguish to stop self-test procedure. And if the battery is detected weak or dead, the Battery Replacement LED will steadily illuminate.

### Caution



**The UPS will remain at “NO” output, if the start-up operation is not proceeded properly even though the Input Power Cord is connected to the wall receptacle.**

### Important Notice



**Plug the UPS onto the wall receptacle to charge the UPS for over 8 hours after initial installation.**

### Storage



Store at -15 to +30 °C (+5 to +86 °F), charge the UPS battery every six months.

Store at +30 to +45 °C (+86 to +113 °F), charge the UPS battery every three months

## CHAPTER 6

### UPS MAINTENANCE

#### **Battery Replacement**

When the UPS is started up or a self-test is executed, the Battery Replacement LED might light up due to battery weak or battery dead.

- 1 When the Battery-Replacement (RED) lights up, you may leave the UPS to be re-charged for at least 8 ~ 10 hours to see whether the RED LED will be extinguished after the Self-test function is executed again.
  
- 2 In case the RED LED remains unchanged, you may unscrew the Easy Swappable Battery cover, replace a new battery then push the "On" Switch to disable the RED LED. Please follow the steps 1-3 to replace the new battery.

**Caution**


**The UPS will remain at “NO” output, if the start-up operation is not proceeded properly even though the Input Power Cord is connected to the wall receptacle.**

**Caution**


**The battery is heavy, pull the battery out onto flat & stable surface.**

**Caution**


**DO NOT DISCONNECT the batteries while the UPS is in the BACKUP mode.**

**How to Replace Battery****STEP 1**

**STEP 2**



**STEP 3**



**Recycling the Used battery**



Contact your local recycling or hazardous waste center for information on proper disposal of the used battery.

**CHAPTER 7**  
**SPECIFICATIONS**

**Power Rating**

Model	Voltage	Power Level	Input Voltage Range
<b>JP-Pro XL 1000</b>	110/115/120 220/230/240	1000VA/600W	-32% to +35% of nominal Voltage
<b>JP-Pro XL 1500</b>	110/115/120 220/230/240	1500VA/900W	
<b>JP-Pro XL 2000</b>	110/115/120	2000VA/1200W	

	220/230/240
<b>JP-Pro XL 3000</b>	
110/115/120	3000VA/1800W
220/230/240	

#### Technical specification

<b>Frequency</b>	45-65Hz± 0.5Hz, Auto Sensing (Normal mode)
<b>Range</b>	50/60Hz± 0.5Hz, Auto Sensing (Backup mode)
<b>Regulation (Normal Mode)</b>	-12 to +8% of nominal voltage
<b>Regulation (Backup Mode)</b>	nominal output voltage ± 0.5%
<b>Voltage Waveform</b>	Sine-Wave
<b>Efficiency</b>	>95%(Normal mode) >80%(Backup mode)
<b>Over load protection</b>	>110% (Normal mode) >120% (Backup mode)

#### Battery

	JP-Pro XL 1000	JP-Pro XL 1500	JP-Pro XL 2000	JP-Pro XL 3000
<b>Battery Voltage</b>	24v	24V	48V	48V
<b>Quantity</b>	4pcs	4pcs	8pcs	8pcs
<b>Type</b>	Sealed maintenance-free, valve-regulated, Lead-acid			
<b>Capacity</b>	7.2AH	9Ah	7.2Ah	9Ah
<b>Recharge time</b>	>4 hours to 90%			
<b>Autonomy</b>	>10min.	>8min.	>10min.	>8min.